TRIUMPH escape™ HD

Escape HD Parts List

Click part # to see parts images

Call out	Part #	Description	UoM
1	500-1516	Backstrap	EA
2	500-1560L	Brake handle assembly (Left)	EA
	500-1560R	Brake handle assembly (Right)	EA
3	500-1009	Anatomical handles (PR)	PR
4	500-1561L	Handle tube (Left)	EA
	500-1561R	Handle tube (Right)	EA
-	500-1562	Brake cable (complete)	EA
5	500-1515	Backstrap connector w. screw	EA
6	500-1535	Handle height adjustment lever (Left)	EA
	500-1536	Handle height adjustment lever (Right)	EA
7	500-3110	Shopping basket	EA
8	500-1598	Seat cushion (Left & Right) - Set	EA
9	500-1096	Handle strap	EA
10	500-1080	Frame lock - Complete Escape	EA
11	500-1073	Seat mechanism (Complete)	EA
12	500-1106	Basket hook (Left)	EA
	500-1107	Basket hook (Right)	EA
13	500-1122	Folding cross bar - Escape HD	EA
14	500-1144	Cross bar screw & nut	EA
15	500-1136	Folding bracket (Escape HD) w. screws	EA
16	500-1446	Front fork assembly - Escape HD (Left)	EA
	500-1446	Front fork assembly - Escape HD (Right)	EA
17	500-1055	Front wheel (200mm) - Complete	EA
18	500-1064	Front axle bolt	EA
19	500-1044	Brake pad (Complete) - Left	EA
	500-1045	Brake pad (Complete) - Right	EA
20	500-1055	Rear wheel	EA
21	500-1059	Rear axle bolt	EA
22	500-1063	Curb climber (Black)	EA